


Lutron® 0–10 V_{DC} Wallbox Controls with a Power Pack and Wired Occupancy Sensor

The NTSTV-DV and DDTV are 0–10 V_{DC} controls for compatible 0–10 V_{DC} LED drivers and fluorescent ballasts. This guide demonstrates how to wire a Lutron® occupancy sensor with the NTSTV-DV or DDTV in the same installation.


Notes:

- Requires the use of a Lutron® PP Series power pack (e.g., PP-DV or PP-347H).
- If the dimmer is in the OFF position, the occupancy sensors will NOT turn the lights on when the room becomes occupied.
- If the dimmer is in the ON position, the occupancy sensor will turn the lights ON to the last set level when the room becomes occupied.
- If the occupancy sensor turns the lights OFF due to time-out and the dimmer remains in the ON position, the occupancy sensor will return the lights to the last set level once the room becomes occupied.
- The green ground wire of the NTSTV-DV can be capped off in this Class 2 installation if no ground connection is present.
- The following wiring installation is valid for Lutron® LOS-CIR, LOS-CUS, LOS-CDT, LOS-WIR and LOS-WDT Series occupancy sensors

Wiring Diagram: NTSTV-DV



Wiring Diagram: DDTV



* For LOS-CDT-500R-WH, LOS-CDT-1000R-WH, LOS-CDT-2000R-WH, and LOS-WDT-R-WH models: Use the gray wire instead of the blue wire to use the photo cell option. The photo cell option prevents the lights from turning on when there is sufficient natural light and is available only with these -R models. These models also contain a separate relay output (yellow/white, black/white, and blue/white wires) that is not needed for this installation.

Lutron is a registered trademarks of Lutron Electronics Co., Inc.

Lutron Contact Numbers

WORLD HEADQUARTERS

USA

Lutron Electronics Co., Inc.
7200 Suter Road
Coopersburg, PA 18036-1299

TEL: +1.610.282.3800
FAX: +1.610.282.1243
Toll-Free: 1.888.LUTRON1

Technical Support: 1.800.523.9466
intsales@lutron.com

North & South America Technical Hotlines

USA, Canada, Caribbean: 1.800.523.9466
Mexico: +1.888.235.2910
Central/South America: +1.610.282.6701

EUROPEAN HEADQUARTERS

United Kingdom

Lutron EA Ltd.
6 Sovereign Close
London, E1W 3JF United Kingdom

TEL: +44.(0)20.7702.0657
FAX: +44.(0)20.7480.6899
FREEPHONE (UK): 0800.282.107

Technical Support: +44.(0)20.7680.4481
lutronlondon@lutron.com

ASIAN HEADQUARTERS

Singapore

Lutron GL Ltd.
15 Hoe Chiang Road
#07-03, Tower 15
Singapore 089316

TEL: +65.6220.4666
FAX: +65.6220.4333

Technical Support: 800.120.4491
lutronsea@lutron.com

Asia Technical Hotlines

Northern China: 10.800.712.1536
Southern China: 10.800.120.1536
Hong Kong: 800.901.849
Indonesia: 001.803.011.3994
Japan: +81.3.5575.8411
Macau: 0800.401
Taiwan: 00.801.137.737
Thailand: 001.800.120.665853
Other Countries: +65.6220.4666