1

# Installation Instructions for Alpha 4 (Halogen Version)

### **IMPORTANT SAFETY INSTRUCTIONS**

To reduce the risk of fire, electrical shock, exposure to excessive UV radiation, or injury to persons:

- Use this fixture indoors only.
- Do not look directly at the lamp while the fixture is on.
- **RISK OF FIRE:** Use only the type of lamp and maximum wattage indicated in this instruction manual.
- Never cover the halogen lamp with anything other than a lamp shield provided by Edge Lighting and never place flammable material close to the fixture.
- Never turn the fixture on and off by connecting and disconnecting the halogen lamp.

#8-32 SCREW

- Do not touch the fixture head, shade or lamp shield while the fixture is on. These surfaces may be **VERY HOT**.

# Install the Fixture


WIRES

#### - Do not touch lamp at anytime. Use a soft cloth instead as oil - This product can be dimmed with a standard incandescent from skin may damage lamp. dimmer. - It is normal for a new halogen lamp to produce minor smoke when first turned on. SAVE THESE INSTRUCTIONS! - Turn power off and allow to cool before replacing lamp.

1718 W. Fullerton Ave

Chicago, IL 60614 Tel: 773-770-1195 Fax: 773-935-5613

www.edgelighting.com info@edgelighting.com



**5:** Secure the canopy to the universal crossbar by tightening the two #8-32 screws through the mounting bracket holes into the two inner threaded crossbar holes.

#### **IMPORTANT INFORMATION**

- This product is ETL listed for indoor dry locations.
- This product is wall mounted only.
- This product can mount to either a 4" square electrical box with round plaster ring or an octagon electrical box.



ALPHA-4-H1-



